

SCUBA HOSE

INSTALLATION INSTRUCTIONS

1



Sleeve Flexo onto your low pressure line on the regulator end or onto whatever line you would like to cover.

2



Slide the Flexo onto the end of your hose, 2" - 3" down on a 36" hose (more on shorter ones) and tape tightly in place with electrical tape over the Flexo, from fitting down onto bare hose.

3



Fold Flexo over itself down the length of the hose. Stretch Flexo snugly over hose. If the Flexo is too long or too short, remove and repeat step 2, adjusting the Flexo accordingly.

4



Tape Flexo in place at the first stage end, to keep it from moving while you feed the hose protector onto hose. Lubricate if necessary. The whole procedure should take 3-5 minutes.

5



Install hose protector onto hose over the Flexo. Your hose is now Identified, Beautified, and Protected with FLEXO